

# Glide Replacement on Stackable Chairs

Tools Needed: Vise grip pliers, Rubber mallet.



Stackable Chair Glides for Carpeted Floors



Optional Nylon Cap for Non-Carpeted Floors



**1) Turn chair over, placing the seat on a solid work surface. Grip glide to be removed with pliers. Remove glide from chair leg with an upward/forward motion.**



**2) Make sure the tubular leg is completely clear before attempting to insert new glide.**

**Note: Once glide has been removed, it cannot be reinstalled.**



**3) Align protective boot of new glide with tubular leg and hold in place. Install glide by striking it firmly with a rubber or impact absorbing mallet until it is seated on chair leg.**

**Note: DO NOT USE A METAL HAMMER DIRECTLY ON GLIDE**