

Glide Replacement on Barstool Bases


Tools needed: Vise grip pliers, Scratch awl, Rubber mallet.



Optional Nylon Cap for Non-Carpeted Floors




1) Turn stool over, placing the seat on a solid work surface. Grip glide to be removed with pliers. Remove glide from stool leg with an upward/forward motion.



2) Remove any remaining expansion clip(s) and nylon spacer that may remain in leg hole.

Note: Once glide has been removed, it cannot be reinstalled.



3) Align stem of new glide with hole in leg and hold in place. Install glide by striking it firmly with a rubber or impact absorbing mallet until it is seated in stool leg.

Note: DO NOT USE A METAL HAMMER DIRECTLY ON GLIDE